




Directions for Swing Master Golf Net and Frame

1	Long Single Pin Piece	2
2	Long Double Pin Piece	4
3	Short One Pin Piece	2
4	One Pin Piece w/ Ring	2
5	Short Double Pin Piece	2
	4-Way Bottom Piece	2
	Angle Corner	2
	90° Corner	2
	Golf Net	1
	Golf Baffle	1




Assemble The Frame

1. **Lay out** all of the steel pieces per the diagram.
2. **Assemble the “back” of the frame** on the ground. That is everything in between the **4-Way Bottom Piece** and the **Angle Corner** including the cross bar.
3. **Assemble the feet** by inserting the 4 poles into the **4-Way Bottom Piece**.
4. **Assemble the top** by combining the rest of the pieces to what you have already done.
5. **Tip the frame forward** on it's feet.


Hang the Net

6. **Hang the Top/Front of the Net** to the **90° Corners**. Do this by inserting the S-Hook through the ring.
7. **Attach the Bottom/Front of the Net** to the **One Pin Piece w/ Rings**. Do this by hooking the S-Hook into the pipe.
8. **Attach the Bottom/Back of the Net** to the ring on the **One Pin Piece w/ Rings**. Do this by inserting the S-Hook into the ring.
9. **Attach the Top/Back of the Net** to the **Angle Corners**. Do this by inserting the S-Hook into the ring. You may adjust the string to achieve your desired net shape.
10. **Tuck the Net Toggles** under the **One Pin Piece w/ Rings**.
11. **Attach the Baffle directly to the frame** using the d-clips that you have fed through the net. The top of the baffle has shorter strings and attaches to the **Angle Corners**, while the bottom clips are connected to the **4-Way Bottom Piece**.

Net Attachment



Baffle Attachment
(Net Removed for Clarity)



Completed Golf
Net and Frame

